

Part Number: Y-S-MAX

Description: Scooter Saddle

Fitment: 2015-2020 Yamaha S Max

Revision: 1



Tools Required	Parts List
10mm socket wrench	

NOTE: We recommend the use of Loctite® or similar threadlock material when assembling parts on your bike.

1. The Corbin saddle is a direct replacement for your OEM seat. The seat is held in place by using the stock front mounting bracket and rear latch bracket that's pre-installed on the Corbin saddle (*Figure 1*).

2. Start by removing your stock seat.

3. Remove the two hex head nuts that are holding the seat bracket to the chassis, using a 10mm socket wrench.

4. Remove the front bracket on the stock seat and transfer it onto the Corbin seat (*Figure 2*).

NOTE: Make sure you mount it in the correct direction.

5. Install the Corbin saddle just like stock, securing with the stock bolts (*Figure 3*).

Enjoy the ride!



FIG 1



FIG 2



FIG 3

Questions? Give us a holler...
800-223-4332
tech@corbin.com