

Part Number: HD-ST8-R0K-S & HD-ST8-R0K-DT
Description: Corbin Saddles with H-D Saddlebags
Fitment: 2008 Harley-Davidson Rocker
Revision: 2



Tools Required	Parts List
8mm Allen key 7/32 Allen key 5/16 Allen key T45 Torx 10mm Socket wrench	4 3/8-16 x 2 1/2" Black socket head cap screw 2 3/8-16 x 2 1/4" Chrome Allen bolts 6 #P11040 3/4" Spacers 2 3/8" flat Washer

1. Start by removing the stock seat from your motorcycle providing access to the mounting area for your new saddle. Refer to your owner's manual if necessary.

NOTE: We highly recommend using a removable strength thread lock product such as Loctite®.

2. Remove your stock bags by lifting up on the lever and then slide it back (*Figure 1*).



3. Remove the plastic on Harley's seat frame by popping it off of the passenger backseat support (*Figure 2*), then by removing the four 6mm bolts, using a 10mm socket wrench (*Figure 3*).




4. Remove the lower bolt on the bag mounting frame with a 7/32" Allen key (*Figure 4*).

5. Loosen the two upper bolts about half way with a T45 torx wrench (*Figure 5*). **Do Not Remove Bolts Yet!**

6. Repeat on the other side.

7. Spread apart the seat mounting brackets and remove the passenger backseat support (*Figure 6*).

8. Remove the bushing and spring (*Figure 7*).



NOTE: Do not lose them in case you want to switch back to your stock seat in the future.

In the following steps, we recommend you get a second pair of hands to help hold the parts, so they don't drop and damage your fender.

9. Next, go back and remove the two upper bolts on the bag mounting frame.

10. Remove the seat side bracket and bolts from the bag mounting frame (Figure 8).

11. Cover your fender to help guard from scratching the paint (Figure 9).

12. Take your Corbin saddle and slide the saddle into place nose first securing the mounting tongue and lower onto the chassis.

13. Reinstall the bag mounting frame back onto the bike by using the supplied socket head cap screws and spacers. Do this by placing the socket head cap screws through the top two holes on the bag mounting frame, then add the spacer (Figure 10), then secure it under the decorative seat skirt, using a 5/16 Allen key. **Do Not Tighten Yet and use Loctite®.**

NOTE: You may need to wiggle the seat around to get the screws and holes to align.

14. Next, secure the lower part of the bag mounting frame. Do this by placing the spacer behind the bag mounting frame and secure with the supplied chrome Allen bolt and stock washer (Figure 11), using a 7/32" Allen key. **Don't forget to use Loctite®.**

15. Repeat on the other side.

16. Tighten all bolts to 12 ft. lbs.

17. Reinstall the bags.



Questions? Give us a holler...
800-223-4332
tech@corbin.com