

**Part Number:** HD-ST8-R0K-S

**Description:** Classic Solo Saddle

**Fitment:** 2008 Harley-Davidson Rocker

**Revision:** 1



Tools Required	Parts List
5/16 Allen key	4 3/8-16 x 1 3/4 x 1/2 black socket head cap screw 4 1/4 x 20 flat Washer 4 3/8 lock washers

1. Start by removing the stock seat from your motorcycle providing access to mounting area for your new saddle. Refer to your owner's manual if necessary.

**NOTE:** We highly recommend using a removable strength thread lock product such as Loctite®.

2. Corbin's Classic Solo mounts easily to your bike very much like stock. Slide the saddle into place nose first securing the mounting tongue (*Figure 1*) and lower onto the chassis. Secure with the included socket head cap screws, lock washers and flat washers, under the decorative seat skirt, using a 5/16 Allen key (*Figure 2*).



**FIG 1**



**FIG 2**

Questions? Give us a holler...

**800-223-4332**  
**tech@corbin.com**