

Part Number: HD-XL-ST-7-GL & HD-XL-ST-7-CGL
HD-XL-CU-7-GL



Description: Gunfighter & Lady Saddle

Fitment: 2007 Harley Davidson Sportster
with 3.3 Gallon Fuel Tank

Revision: 1

Tools Required	Parts List
Phillips Screwdriver 5/32" Allen Wrench	

NOTE: We highly recommend using a removable strength thread lock product such as Loctite® on the bolts when installing your mounting bracket.

1. Start by removing the stock seat from your motorcycle. Refer to your owner's manual if necessary.
2. Test fit the saddle and adjust bracket position as required (*Figure 1*). Remove saddle and tighten tab mounting bolts with a 5/32" Allen wrench.
3. Your new Corbin saddle is now ready to install by slipping the nose tab of the seat into the front slot and securing the rear tab tightly with the stock mounting bolt. (*Figure 2*)



FIG 1



FIG 2

Questions? Give us a holler...
800-223-4332
tech@corbin.com