

SADDLEBAG KIT KIT P/N 2874305



Application

Victory Vegas™
Victory Kingpin™

NOTE: This kit must be used in conjunction with the appropriate Saddlebag Brackets Kit.

Before you begin, read the instructions and make sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Components:

Qty.	Part Description	Part No.
1	Hard Saddlebag Assembly, Left-Hand	2632895
1	Hard Saddlebag Assembly, Right-Hand	2632896
6	Spacer, Shoulder	5134056
6	Flat Washer, 8 x 1.6	7556045
6	Socket-Head Screw, M8 x 25	7518053
1	Instructions	9919186

You will need to supply:

Torque Wrench
6mm Hex Drive Tool, adaptable to Torque Wrench

NOTE: Make sure the motorcycle kickstand is fully extended and the vehicle is stabilized on a flat surface.

IMPORTANT: For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

1. From the outside of the right-hand bag, insert three shoulder spacers into the mounting holes on the bag. Ensure spacers are oriented so the larger diameter will be between the saddlebag and the bracket.
2. Position the saddlebag so the holes in the bag are aligned with those in the saddlebag bracket.
3. Using three screws and washers from the kit, mount the saddlebag to the bracket. The screws and washers are inserted through the bracket, into the bag as illustrated.
4. Torque the screws to 12 ft. lbs. (16.3 Nm).
5. Mount bracket and saddlebag to the motorcycle, following the procedure detailed in the bracket kit instructions.
6. Repeat all steps for the left-hand bag.

