

Part Number: S-BLVD-5-BAG

Description: Beetle Bags

Fitment: 2005 Suzuki Boulevard C-90

Revision: 2



Tool Required	Parts List
5/8 Open wrench 9/16 Open wrench 6mm Allen wrench 5mm Allen wrench	1 #A00680 Right mounting bracket 1 #A00681 Left mounting bracket 4 #P10071 Spacers 4 Stainless steel studs 4 3/8 Chrome acorn nuts 6 3/8 Lock washers 6 3/8 Flat washers 2 3/8 x 16 x 3/4 Hex Head Bolts

NOTE: We highly recommend using a medium strength thread lock product, such as Loctite®, on all of the bolts when installing your Corbin Beetle Bags.

1. Remove the 2 bolts on the right (pipe side) passenger foot peg mounting bracket.

2. Insert the Corbin lower bracket between the foot peg bracket and chassis, oriented with the mounting arm, towards the rear of the bike. (Figure 2) Reinstall the passenger peg using the original mounting bolts. (Figure 3) Use Loctite® and tighten to 12 ft lbs.

3. Remove the two bolts shown in the chrome fender struts and replace with the stainless steel studs provided. Reuse the stock washers under the studs and install as follows:

- A) If you are using the Suzuki Boulevard sissy bar assembly, install the studs (with washers) directly through the sissy bar bracket as shown. (Figure 4) Use Loctite® and tighten securely.
- B) If you are NOT using the sissy bar, apply the Corbin provided spacers along with the stock washer and install as shown. (Figure 5) Use Loctite® and tighten securely.



4. Carefully line up the two top mounting holes with the two threaded studs you've just installed. Slip the bag onto the studs completely and secure finger tight with the provided flat washer, lock washer and chrome acorn nut.

5. Align the lower mounting hole with the foot peg bracket and secure with the provided hex head bolt, flat washer and lock washer.

6. Once all three locations are aligned, you can tighten them. Use Loctite® and tighten to 8 ft lbs.

7. Repeat on the opposite side and get ready to go for a ride!

Remember: When loading small, heavy objects in the bags (like disc locks) place them in carefully and load as close to the centerline of the bike as possible. If you "throw" such items into the bags, you can cause stress cracks on the outside of the saddlebags.



Questions? Give us a holler...
800-223-4332
tech@corbin.com