

**Part Number:** Y-MJSTY-4-F, Y-MJSTY-4-R &  
Y-MJSTY-4-SMUG



**Description:** Front, Rear & Smuggler Saddle

**Fitment:** 2005 - 2006 Yamaha Majesty 400

**Revision:** 1

Tools Required	Parts List
4 mm Allen wrench 5 mm Allen wrench 6 mm Allen wrench 13 mm Socket or combination wrench	<b>Install Kit for Rear Seat includes:</b> 2 Corbin "L" brackets #A00728 2 m8 x 1.25 x 35 hex head bolts 2 m8 lock washers 2 m8 x 1.25 x 20 chrome button head screws 2 m6 hex head bolts 2 m6 flat washers

**NOTE:** We recommend the use of Loctite® or similar threadlock material when assembling parts on your bike.

1. **Front Saddle:** The Corbin front saddle is a direct replacement for your OEM seat. The seat is held in place with four bolts indicated in *Figure 1*. Simply open the trunk, remove these bolts and replace the seat.



FIG 1

2. Position of the saddle is adjustable. Simply choose the bolt location you find most appropriate as in *Figure 2* and tighten to 6 ft. lbs.



FIG 2

3. **Rear Saddle:** In order to incorporate support for a passenger backrest, we created a stronger mounting system than the stock system.

4. Install the two Corbin "L" brackets at the locations shown in *Figure 3*.



FIG 3

5. Leave the stock spacer in place and secure the bracket with the included m8 x 1.25 x 35 hex head bolts and a lock washer. Use Loctite® on these bolts and tighten to 8 ft. lbs. Notice how they are perpendicular with each other with the longer leg pointing up and the bend to the outside of the bike (Figure 4).

6. If you will be using the Corbin passenger backrest, install it now so you can insert the safety screw under the saddle to lock it in place.

7. Slide the passenger seat into place rear first to engage the seat tongue and lower it down between the two Corbin brackets.

8. Lift the skirt on the side of the seat (Figure 5) and secure it to the Corbin bracket with the included chrome button head screws. Use Loctite® and tighten to 6 ft. lbs.

9. **Smuggler Trunk:** You will use the same "L" brackets that was used for the rear saddle.

10. To install the Smuggler trunk, simply slide the trunk into place rear first to engage the seat tongue and lower it down onto the two Corbin brackets. *Figure 6*

11. Bolt the smuggler trunk to the brackets from the inside of the trunk, using the supplied 6mm bolts and flat washers. Tighten to 6 ft. lbs. (*Figure 7*)



Questions? Give us a holler...  
**800-223-4332**  
tech@corbin.com