

Part Number: Y-LNR-CHIN

Description: Chin Spoiler

Fitment: 2006 Yamaha Road Liner & Stratoliner

Revision: 1



Tools Required	Parts List
4mm hex key (Allen wrench) 5mm hex key (Allen wrench)	Corbin upper mounting bracket 1 m6 x 1.0 x 20 button head screw 1 m6 flat washer 1 m8 x 1.25 x 25 button head screw 1 5/16 flat washer 1 spacer

NOTE: We recommend using Loctite® or similar threadlock material when assembling parts on your motorcycle.

1. Before you start wrenching, check Figure 1 and make sure you've got the correct and complete installation kit.

2. Install the upper mounting bracket first. This uses one screw on each side of your bike near the frame down tube. Refer to Figures 2 and 3. Note the mounting tab on this bracket faces UP.

3. On the LEFT side of the bike, use the included m6 x 20 button head screw along with the supplied washer. On the RIGHT side, reuse the stock hardware. Use a drop of Loctite® and torque both of these to 6 ft lbs.

4. Positioning the bracket. We've found that when in place, the bracket pretty much orients itself because of the way it works around the Yamaha parts. If you find the bracket doesn't line up when you're ready to place the Spoiler, you may need to loosen these bolts and rotate it slightly.

5. At the bottom, the spoiler uses the two bolts shown in Figure 4. Remove these two bolts now.

6. Turn the bars to either side to allow room for the chin spoiler to slide into place. Insert the included spacer into the top mounting hole and position spoiler. Secure at the top with the included m8 x 25 button head screw and 5/16" washer. Secure at the bottom reusing the stock hardware.

Use a drop of Loctite and tighten all three of these to 10 ft. lbs.

That's it, hit the road Jack!

Questions? Give us a holler...

800-223-4332
tech@corbin.com

