

Part Number: HD-ST18-xx-E

Description: Heated Saddle models

Fitment: 2018 & Up Harley-Davidson Softail models

Revision: 2.0



PARTS LIST

1 #SP02028 Small Fuse Adapter (early model)	1 #SP01402 Wire Harness
1 Wire Harness	1 #A01407 Wire Harness
1 #FUSE-B-SMALL Wire Harness Cover	
1 7.5A Small Fuse	

HEATER INSTALLATION

There are different wiring setups available for the Softail models: Earliest models will use a fuse adapter and harness, while later models plug directly into the OEM harness with one of our adapters (Fig 1).

You can determine which option your bike requires by reviewing Figures 2, 6 and 9.

Option A - Fuse Adapter

1. Remove left side cover.

2. If your motorcycle has the plug shown in Figure 2, you will use the Early Model pigtail.

3. Disconnect battery negative terminal.

4. Insert the provided 7.5 Amp fuse into the fuse adapter if not already in place.

5. Disconnect the Accessory cable shown in Figure 2 from the holder. Remove the fuse and insert into Corbin fuse adapter.

6. Insert Corbin fuse adapter in place of the fuse removed in the prior step (Fig 3).

7. Cover the Accessory cable and adapter with provided cover (Fig 4).

8. Find a convenient place to ground the black wire of Corbin pigtail. We used the spot shown in Fig 5.

9. Route the harness under the subframe and connect the fuse adapter to Corbin harness using the spade connector.

cont.



Option A - continued

10 Reconnect battery negative terminal.

11. Plug wiring harness into seat and test. If switch illuminates in ON position, heater is working.

12. Collect together excess wiring, bundle neatly, zip tie and secure as needed.

13. Re-install left side panel and mount saddle.

NOTE: In this installation, heater is not controlled by ignition and must be turned off when not in use.

Option B - Direct Harness #SP01402

1. Remove left side cover.

2. If your motorcycle has the plug shown in Figure 6, you will use harness #SP01402 shown in Fig 1.

3. Disconnect the Accessory cable shown in Figure 6 from the holder.

4. Plug the Corbin wiring harness into the connector as shown in Figure 7.

5. Route the harness under the subframe and secure with zip ties as needed.

6. Plug harness into seat and test. For this installation the motorcycle ignition should be on. If switch illuminates when ON, heater is working.

7. Re-install left side cover and mount saddle.

Option C - Direct Harness #A01407

1. If your late model Softail has the two bullet connectors on top of the fender as shown in Figure 9, use Corbin's harness #A01407.

2. Uncap either of the power ports shown and insert the Corbin connector as shown in Figure 10.

3. Plug harness into seat and test. For this installation the motorcycle ignition should be on. If switch illuminates when ON, heater is working.



4. Optional: You can secure the Corbin harness with the provided zip ties if you prefer though it is not required.

5. When installing the saddle, please be sure the harness wire is not pinched or crushed by any part of the seat or rubber bumpers.

6 Enjoy the ride!



WARNING!

Heater elements should **NEVER** be installed in motorcycle seats used by riders that cannot sense heat.

Questions? Give us a holler...

800-223-4332

corbin01@corbin.com