

Part Number: H-18-GW-DOOR

Description: Expanded Capacity Saddlebag Doors

Fitment: 2018-2019 Honda Goldwing 1800

Revision: 2



Tools Required	Parts List
Phillips Head Screwdriver Needlenose Pliers Angled Pick or Something Similar 3-32 Allen Wrench	2 #SP00302 8-32 x 3/4" Bolts 2 #SP00215 8mm Flat Washers 8 #SP00201 8-32 x 1/2" Chrome Button Head Allen Bolts 10 #SP01015 Flat Washers

NOTE: It would be helpful to have a second set of hands during this installation to help hold some of the parts in position.

1. Start by removing the bolt on the door stay, using a Phillips screwdriver (*Figure 1*).
2. Next, use an angled pick or a similar tool to pull back the clip on the shock to disconnect (*Figure 2*).
3. Lower the bag door and remove the safety screws on all three hinges (*Figure 3*).
4. Use an angled pick to push the pin through the hinge (*Figure 4*), to make it easier to grab and remove with the needlenose pliers (*Figure 5*).
5. Remove the bolts on the OEM latches, using a phillips screwdriver and transfer the latches onto the Corbin lid, using the supplied 8/32" chrome button head Allen bolts and flat washers (*Figure 6*).



6. Install the Corbin lid onto the OEM bags by reusing the OEM pins and safety screws.

NOTE: The pre-installed and aligned brackets on the lids can rotate slightly.

7. Connect the shock onto the Corbin lid.

8. Connect the door stay onto the Corbin lid by flipping the stock spacer and then secure with the supplied bolt and washer (*Figure 7*).



Questions? Give us a call!
800-223-4332
daytona@corbin.com