

**Part Number:** H-FURY-KO  
**Description:** King & Queen Saddle  
**Fitment:** 2009 Honda Fury  
**Revision:** 1



Tools Required	Parts List
3/16" Allen wrench 5/32" Allen wrench Loctite® or similar	

**NOTE:** We highly recommend using a medium strength thread lock product, such as Loctite®, on all of the bolts when installing your Corbin saddle.

1. To install your new Corbin saddle, you're first going to have to remove the stock seat. Refer to your owners manual if necessary.
2. In order to install your Corbin saddle, the backing plate must be removed. To do this, remove the three Allen bolts using a 5/32" Allen wrench (*Figure 1*).
3. To install your King and Queen saddle, simply slide the two front tongues under the chassis then align the bracket on the rear of the saddle to the hole in your fender (*Figure 2*) and secure with the stock bolt (*Figure 3*).

**NOTE:** Bracket on the rear of the saddle is adjustable (*Figure 4*).

4. Reinstall the backing plate, being careful not to over-tighten and crack the plate.



Questions? Give us a holler...  
**800-223-4332**  
tech@corbin.com