

Part Number: KTM-12-SA-21(E)

Description: Canyon Dual Sport Saddle

Fitment: 2021-2022 KTM 1290 Adventure R

Revision: 1



Tools Required	Parts List
Scissors	1 KTM Wiring Harness 1 Zip Tie

Saddle mounts to your KTM just like stock with brackets preinstalled on the Corbin seats.

1. Remove stock seat.
2. To install the Corbin saddle, simply slide the saddle into place nose first to engage the tongues and lower the rear into place. Push firmly on the passenger platform to latch. (Figure 1)

HEATER INSTALLATION:

1. Included with your electric heated seat you will find a short wiring pigtail with built in fuse.
2. Route the pigtail under the frame (Figure 2).
3. Connect the red wire with built in fuse to the stock brown connector and connect the black connector to the stock black connector (Figure 3).
4. Secure the pigtail with the provided zip tie... just secure it in place for cleanliness (Figure 4).
5. You are now ready to install your saddle. Simply plug the wiring harness into the seat and test. To do this, turn on your ignition switch and flip the switch on the saddle. If the switch illuminates, the saddle heater is working.
6. Install the saddle as outlined above.

NOTE: The heater is controlled by the switch along the side of the saddle. The temperature is regulated by an internal thermostat when the heater switch is turned on.

Enjoy your new saddle!

Questions? Give us a holler...
800-223-4332
tech@corbin.com

