

Part Number: T-TGR-8-11-GL(E)

Description: Canyon Dual Sport

Fitment: 2011-2018 Triumph Tiger 800 & Tiger 800 XC

Revision: 1



Tools Required	Parts List
10mm socket or Combination wrench	1 Wiring Harness Fuse Line 12"

SADDLE INSTALLATION:

1. Remove your stock seat. Refer to your owner's manual if necessary.
2. Saddle mounts just like stock with brackets preinstalled on the saddle.
3. To install your Canyon Dual Sport, slip the front tongue of your saddle at the rear of the gas tank, align the Corbin latch pin to the stock bracket and push down on the saddle until you hear the lock click.



HEATER INSTALLATION:

1. Using a 10mm combination wrench, disconnect the battery negative terminal.
2. Using a 10mm socket wrench, disconnect the battery positive terminal and attach the positive wire to the battery.
3. Re-attach the battery negative.
4. Plug the wiring pigtail on the Corbin saddle into the wiring harness you just installed. Flip the switch on the saddle. If the switch illuminates, the saddle heater is working.

NOTE: The heater is controlled by the switch along the side of the saddle. The temperature is regulated by an internal thermostat when the heater switch is turned on.

WARNING: The heated seat will **NOT** turn off when the ignition is turned off. You must turn off your heated seat when not in use.

Questions? Give us a holler...

800-223-4332
tech@corbin.com