

**Part Number:** HD-LW-ONE(E)

**Description:** Dual Saddle

**Fitment:** Harley-Davidson Livewire ONE

**Revision:** 1



### Parts List




- 1 #A01305 Hinge
- 1 #P11331 Latch Bracket
- 1 6mm Allen Bolt
- 1 6mm Flat Washer
- 3 #SP00244 Allen Bolts
- 3 #SP00214 Flat Washers

### Tools Required

- T-25 Torx Wrench
- Phillips Screwdriver
- Pick

**NOTE:** We recommend the use of Loctite® or other threadlock compound when assembling parts on your motorcycle.

1. Open seat.
2. Remove the two bolts on the tank panel, using a T-25 torx wrench (*Figure 1*).
3. Remove tank panel by pulling up and out (*Figure 2*).
4. Using a pick, remove the C-clip on the seat hinge (*Figure 3*), then pull out the spring loaded bolt and washer (*Figure 4 & 5*).
5. Remove the two bolts on the seat hinge, using a T-25 torx wrench (*Figure 6*).
6. Remove seat.
7. Remove the OEM bracket from the stock seat and install it onto the Corbin seat, using the provided Allen bolts and flat washers (*Figure 7*).
8. Install the Corbin tank cover by sliding it into place and securing with the stock bolts and washers.



9. Install Corbin's rear hinge bracket by sliding it into place and securing with the stock bolts (Figure 8).

**NOTE:** Rear frame is a little flexible to help get the bracket in place.

10. Secure the bracket to the liner, using the provided 6mm Allen bolt and flat washer (Figure 9).

11. Install the Corbin seat onto the Corbin hinge bracket (Figure 10).

12. Hinge saddle down, pull lever and push the nose down until it engages. Slight adjustment is possible if needed.

13. Remove the bottom bolt on the 12v battery cover (Figure 11).

14. Pull out battery, disconnect the negative wire, then disconnect the positive wire, using a Phillips screwdriver.

15. Route the provided pigtail down the frame behind the latch mechanism (Figure 12), leaving approximately 12" of wiring to connect to the saddle. Then route the pigtail down the side and through the cavity (Figure 13) and out towards the battery (Figure 14).

16. Zip tie wires so they are neatly out of the way. Do not over tighten as to not damage the wires.

17. Connect the red wire to the positive location and connect the black wire to the negative location (Figure 15).

18. Put the battery back in place and re-bolt the battery cover.

19. Plug pigtails together.



FIG 8



FIG 9



FIG 10




FIG 11



FIG 12




FIG 13



FIG 14



FIG 15

Questions? Give us a holler...  
**800-223-4332**  
**tech@corbin.com**