

**Part Number:** HD-VR-YWFAIR

**Description:** Fleetliner Fairing

**Fitment:** Harley-Davidson V-Rod

**Revision:** 1



Tools Required	Parts List
5mm Allen wrench 6mm Allen wrench 8mm Allen wrench 7/16" Allen wrench 5/8" combination wrench 1/2" combination wrench	1 #A00927 Mounting bracket (right side) 1 #A00926 Mounting bracket (left side) 1 #P00802 Headlight spacer 2 8m x 1.25 x 80 Allen head cap bolts 2 5/16 x 24 x 5/8 Chrome button head Allen screws 4 5/16 Lock Washers 4 10 x 70mm Button head Allen bolts 4 3/8" Flat washers 4 8m x 1.25 x 40 Chrome button head Allen screws 4 5/16" Chrome flat washers 3 6m x 16 Chrome button head Allen screws 3 1/4" Chrome flat washers

**EXTREME CAUTION:** To prevent injury or damage to your bike, you should not attempt to install the fairing without a jack. The jack will help take the load off of the front tire.



**NOTE:** We recommend the use of a thread lock product such as Loctite® when assembling parts on your motorcycle.

1. Remove the stock fairing by removing the two bolts holding the headlight as shown in *Figure 1*.

2. Pull out 2" of slack in the headlight wiring and reinstall with the provided 8m x 1.25 x 80m Allen head cap bolts and the aluminum headlight block (*Figure 2*). Tighten to 12 ft. lbs. and don't forget the Loctite®.

3. Starting on the right side, unbolt the turn signal swivel using a 5/8" combination wrench (*Figure 3*) and remove turn signal from the swivel using a 1/2" combination wrench (*Figure 4*). There is a plastic wire holder that attaches the turn signal wiring to the handlebar. Remove the holder from the bar so you can detach the turn signal wiring. Reinstall plastic holder to handlebar.

4. Mount the turn signal onto the Corbin side bracket #A00927 using the included 5/16" x 24 x 5/8" chrome button head Allen bolt and two lock washers. Place a lock washer between the turn signal and Corbin bracket, then secure with a lock washer and chrome button head Allen bolt. Refer to *Figure 5*.



5. Remove the bolts from the top and lower triple clamp. (Figure 6)

6. Install the Corbin bracket onto the triple clamp using the supplied 10 x 70mm button head Allen bolts and 3/8" flat washer (Figure 7). Tighten to 12 ft. lbs. and as always, Loctite® is a good idea.

7. Repeat this procedure on the other side.

8. You are now ready to place the fairing and attach it to the brackets. You can most likely position the fairing and have it sit by itself while you bolt it on, but we think it's a good idea to have a friend help. Just to guard from scratching the new paint.

9. Secure the fairing to the bracket with the 8m x 1.25 x 40 chrome button head bolt and 5/16" flat washer at each of the four locations. Use Loctite® on these bolts and tighten to 10 ft. lbs.

Your fairing installation is completed. Remove the jack and go for a ride. *Enjoy!*



FIG 3




FIG 4



FIG 5




FIG 6




FIG 7



FIG 8

Questions? Give us a holler...  
**800-223-4332**  
**tech@corbin.com**