

**Part Number:** KV-2-FAIR

**Description:** Trimtab Fairing

**Fitment:** 2004 Kawasaki Vulcan 2000

**Revision:** 1



Tools Required	Parts List
10mm open end wrench or socket with ratchet 17mm open end wrench or socket with ratchet 8mm allen wrench 4mm allen wrench 3/16" allen wrench Loc-tite® or similar thread lock. <b>REMOVABLE STRENGTH</b>	Fairing mounting bracket cover 4 M10x40mm hex head 4 SAE flat washers 2 BHC M8x25mm SCH 2 SAE 5/16 flat washer chrome 2 BHC M6x40mm SCH 2 5/16 wave washers

**NOTES:**

It would be helpful to have a second set of hands during this installation to help hold some of the parts in position while installing the fairing.

Since we'll be working directly over the gas tank, you may want to protect it with a mat or towel to avoid any damage.

We highly recommend using a removable strength thread lock product, such as Loc-tite®, on the bolts when installing your fairing.


**INSTRUCTIONS:**

1. Start by removing the chrome ignition switch cover using the 4mm allen wrench to remove all 4 screws (*Figure 1*). Next, remove the 2 screws holding the headlight (one on each side) then unplug the headlight and put to the side (*Figure 2*). Refer to your owner's manual if necessary.

2. To relocate the ignition switch, we'll loosen up the wiring loom by unhooking loom clip on the left side of the housing then pulling the wire connector free from it's mounting clip on the center column (*Figure 3*). Refer to your owner's manual if necessary.

3. Using the 10mm wrench, unbolt the ignition switch and move to the side. (*Figure 4*)

4. With the 8mm allen wrench, remove the 4 bolts holding the handle bar clamps together (*Figure 5*). Being careful to not allow the bars to drop, mount the Corbin fairing mounting bracket on top of the handle bar clamps using the same holes, then secure with the provided 10mm bolts and lock washers.



5. With the bracket in place, you can now mount the ignition switch to the right side of the bracket reusing the original bolts (Figure 6). Reinstall the headlight.



6. Now it's time to install the Corbin ignition cover. Slip the cover over the handle bar clamps, align the four bolts holes and secure with the original bolts (Figure 7).

**NOTE:** Make sure the rubber seal around the ignition switch stays in position to protect it from moisture.

7. Install the fairing adjuster to the fairing mounting bracket using the supplied 5/16-24 x 3/4 chrome button head bolts, tighten using a 3/15" allen wrench (Figure 8).

8. Align the bottom hinge, position it over the fairing-mounting bracket and secure with 1/4-20 x 3/4 chrome button head bolts (Figure 9).

9. Using your finger, bend the safety tabs up covering the bolts on each side of the horizontal threaded rod for additional security (Figure 10).



Questions?  
Give us a holler...  
**800-223-4332**  
tech@corbin.com