

Part Number: KV9-6-YLNRFAIR

Description: Touring Fairing

Fitment: 2006 Kawasaki Vulcan 900

Revision: 1



Tools Required	Parts List
5 mm Allen wrench 14 mm Socket wrench	1 #A00825 Chrome fairing bracket (center) 1 #A00826 Chrome fairing bracket (left) 1 #A00827 Chrome fairing bracket (right) 6 m8 x 1.25 x 40 Chrome button head Allen bolts 2 m8 x 1.25 x 20 Chrome button head Allen bolts 8 8mm Flat washers

NOTE: We recommend the use of Loctite® or other threadlock material when assembling parts on your motorcycle.

1. Assure that you have all of the parts necessary for installation. The two Corbin fairing mount brackets are NOT the same but are a near mirror image of each other.


2. Fairing installation is simple and requires only that our brackets be installed onto your front end with the included bolts.

3. To install, remove the bolts on the triple clamp that's holding the handlebar risers, using a 14mm socket wrench. Place the Corbin center bracket into position and secure with the stock bolts (*Figure 1*). Tighten to 15-18 ft. lbs.

4. Remove the bolt from the light bar of the triple clamp using a 5mm Allen wrench (*Figure 2*). Do this one side at a time just to keep things easy.

5. Now position the Corbin bracket and secure with the supplied m8 x 1.25 x 40 chrome button head bolts and flat washer, using a 5mm Allen wrench (*Figure 3*). Use Loctite® on these bolts and tighten to 10 ft. lbs.

6. Next, secure the side bracket to the center bracket on the top clamp with the supplied m8 x 1.25 x 20 chrome button head bolt and flat washer (*Figure 4*). Tighten to 10 ft. lbs.



7. Repeat this procedure on the other side. (Refer to figure 5 to view the positioning of the mounting brackets)

8. You are now ready to place the fairing and attach it to the brackets. You can most likely position the fairing and have it sit by itself while you bolt it on, but we think it's a good idea to have a friend help. Just to guard from scratching the new paint.

7. Secure the fairing to the bracket using the supplied m8 x 1.25 x 40 chrome button head bolt and flat washer at each of the four locations (Figure 6). Use Loctite® on these bolts and tighten to 6 ft. lbs.

NOTE: Fairing was designed with handlebars and mirrors in the stock location. Check clearance so vibrations won't bring fairing into contact with painted objects.



FIG 4



FIG 5



FIG 6

Questions? Give us a holler...
800-223-4332
tech@corbin.com